

## ECMLink Device Install Instructions

Chip orientation:

1. Open case by removing four black screws.
2. Inside the case, note chip orientation as shown in the illustration below. The new device will have to be installed as shown. It **can** be installed backwards, so please observe the proper orientation.



**Notch goes here**